

PRE-FRAMED & GROUTED MURAL - MOUNTING INSTRUCTIONS

STEP 1


Position the supplied cleat horizontally on the wall, so that the screw holes are approx. 6" below the desired location for the top of the mural. Use a level for best result. Mark the positions of the screw holes with a pencil.



STEP 2

Drill appropriately sized pilot holes at these marked points.

**Screws are not provided, and should be selected based on your wall surface.



STEP 3

Fasten the cleat to the wall using appropriately sized screws into the pilot holes.

**Wall anchors rated to hold a minimum of 50lbs. are required if installing into sheetrock.



STEP 4


Slide the mural down to interlock the two cleats, applying gentle downward pressure.

** Important - please proceed to Step 5 to install safety catch, ensuring a secure installation




STEP 5

After hanging the mural, mark the bottom edge of the frame on the wall using a pencil. Also mark the horizontal center of the frame on the wall.



STEP 6

Temporarily remove the mural from the wall by applying upward pressure while holding firmly. Measure up 1/2" from the center of horizontal pencil line drawn on the wall in the previous step. Mark this location and drill a hole using a 5/16" drill bit (not provided). Install the included wall anchor into this hole.



STEP 7

Install the T-Head Safety Screw using the slotted wrench (both included). Screw into the wall so that no threads are exposed. The flat neck should stick out from the wall in a horizontal (unlocked) position. Re-hang the mural, making sure the T-head screw passes through the pre-installed bottom mounting plate.



STEP 8

Secure the mural to the wall by turning the safety screw a quarter turn using the provided slotted wrench. The flat scw head will now be in a vertical orientation, locking the mural to the wall. Gently tug on the mural to ensure it is locked in place.

